Sunday Morning Audio Checklist

Effective Date 7.24.22

Stage

- 1. Plug in iPad interface and ensure its charging
- 2. Check power amps (Figure 1). If off, turn them on.
- 3. Position Vox wireless road case rack and remove covers.
- 4. Snap power cable into power port and plug into outlet (Figure 2).
- Locate stage ethernet cable bundle (blue), usually hanging on wall behind stage audio console, and find cabled labeled "E1".
- 6. Insert ethernet cable "E1" into Port A on Wireless rack (Figure 2).
- 7. Assemble both antennas and place them on stands arms with apart.
- 8. Patch instruments.
- 9. Patch iPad Interface
- 10. Make sure both power switches are on. One is located on the bottom on the back of the rack, the other is located on top in the front (Figure 6).
- 11. Position Item rack on stage.




Figure 1 Power Amp Stack (House)

Front of House

Can be done before stage setup is complete.

- 1. Place DiGiCo Console on Table
- 2. Remove Cover and Lid
- 3. Remove IPod and talkback mic from case and place in a convenient location
- 4. Plug white power strip into outlet.
- 5. Turn on power switch (located just under power cable port, Figure 4)
- 6. Find ethernet bundle (blue), usually located underneath the house console. Located ethernet cable labeled "E1".
- 7. Plug ethernet cable into bottom left ethernet port (Figure 4).
- Plug in output to power amps (house), labeled main left, main right, subs, fills (Figure 3). Can be found either on floor or plugged into house console
- 9. Plug in patch to livestream on both the DiGiCo console and the livestream rack.
- 10. Optional: Perform virtual sound check.



Figure 2: Rear of Wireless Rack (Vox)



Figure 4: FOH Console Rear (Vox)



Figure 3: Power Amp Output Patch (House)




Figure 6: Wireless Rack Front (Vox)

	12:38 PM Sun Jul 24	HFD 7/24/2022	 €< 600 (D)
	General Trac	cs Buses MIDI	About 🛞
0	Click	1 > Acoustic Guitars	8 >
	Guide	2 > Strings	10 >
	Drums	10 > Horns	10 >
	Percussion	10 > Pad	10 >
	Loops	10 > Vocals	10 >
	Bass	4 > FX	3 >
	Piano	5 > Aux	10 >
	Keys	10 > SMPTE	None >
	Electric Guitars	7 >	
	2	1915	
		CAV C	: 01
		TUNS	
		- 5.46	
	Reset Default Settings	tvil C	

Figure 5: iPad Bus List. Corresponds to XLR ports on back of case.